




ShaferTM

HAND PUMP - DOUBLE HOLDING VALVE MAINTENANCE AND SERVICE MANUAL




BASIC CHECK-OUT PROCEDURES

The following three tests illustrate the proper working functions of the shafer hand pump. Failure of any of these procedures may result in operating problems for the valve operator.




Test 1

With both palm buttons out (automatic position) and with the ram in the "UP" position and fluid in the pump cylinder, stroke the hand pump. - If the ring seals, valve sleeves and the manual discharge check ball are sealing properly, it should be impossible to pull the pump ram down. The ram can be lowered or pulled down by holding in the manual discharge relief and pulling the ram down at the same time.



Test 2

With one palm button in (either open or close position) and pulling the pump ram up, fluid is being pulled up into the pump cylinder. If the pump fails in the suction cycle, an immediate inspection should be made of the oil reservoir to which the suction of the pump is connected. Check to determine if there is hydraulic fluid in the tank. If there is fluid in the reservoir tank and the pump fails in the suction cycle, the pump and valve assembly should be disassembled and checked as shown in a later illustration.




Test 3


The final test is accomplished by pushing in the palm button to whatever position the valve is in, "open" or "closed". Raise the pump handle to draw fluid into the cylinder and then force the ram downward. The ram will discharge fluid until the actuator is fully stroked (open or closed). When the gate actuator is fully stroked, there will be no leaking across the seals and the ram will not move downward after the gate actuator is fully stroked until the manual relief is pushed in and the ram pulled down.

GAS HYDRAULIC SYSTEM CIRCUIT


Shown with Linear operator.



GAS-HYDRAULIC HAND PUMP






Note: Item (108) 7/16-14 Cap Screw
Torque: 30 Ft./Lb. Dry; 24 Ft./Lb. Lub.




Bill of Material

1	Pump Body	70 Duro
2	Pump Head	Teflon
3	Packing Gland	70 Duro
4	Clevis	70 Duro
5	Pilot Bar	70 Duro
6	Pump Piston	70 Duro
7	Top Ram	90 Duro
8	Bottom Ram	Teflon
9	Ram Protective Cover	70 Duro
10	Pump Suction Seat	70 Duro
11	Clevis Pin S.S.	70 Duro
12	Clevis Pin S.S.	70 Duro
13	Valve Body	70 Duro
14	Suction Cap	70 Duro
15	Pilot Piston	70 Duro
16	Right Valve Sleeve	70 Duro
17	Left Valve Sleeve	70 Duro
18	Ring Seal	70 Duro
19	Ring Seal	70 Duro
20	Valve Cap	70 Duro
22	Operator Port Cap	70 Duro
23	Relief Stem	70 Duro
24	Relief Seat	70 Duro
25	Relief Cap	70 Duro
26	Stem	70 Duro
27	Seat Poppet Guide	Teflon
28	Poppet Pin	70 Duro
29	Poppet	70 Duro
30	Poppet Guide	70 Duro
31	Piston	70 Duro
33	Holding Valve End Cap	70 Duro
34	Palm Valve End Cap	70 Duro
35	Discharge Check Seat	70 Duro
36	Flow Control Check Valve Plug Sub Assy.	70 Duro
37	Nylon Ball	70 Duro
38	Flow Control Cap	70 Duro
39	Flow Control Stem	70 Duro
40	Acetal Bearing	70 Duro
41	Acetal Bearing	70 Duro
42	Head Bolt-Hex Hd. Cap Screw-S.S.	70 Duro
43	Valve Bolt-Hex Hd. Cap Screw-S.S.	70 Duro
44	Top Ram Spring Pin	70 Duro
45	Bottom Ram Spring Pin	70 Duro
46	Stem Spring Pin	70 Duro
47	Flow Control Stem Spring Pin	70 Duro
48	Stem Boot	70 Duro
49	Relief Valve	70 Duro
50	Stem Knob	70 Duro
51	Relief Knob	70 Duro
52	Flow Control Knob	70 Duro
53	X-Washer	70 Duro
54	Upper Ram Seal	70 Duro
55	Pump Head O-Ring	70 Duro
56	Ram O-Ring	70 Duro
57	Ram Wiper	70 Duro
58	Piston O-Ring	70 Duro
59	Piston Guide Ring	70 Duro
60	Ring Seal O-Ring	70 Duro
61	Ring Seal O-Ring	70 Duro
62	Valve Cap O-Ring	70 Duro
63	Pilot Piston O-Ring	70 Duro
64	Pilot Piston Guide Ring	70 Duro
65	Pilot Piston Back-Up Ring	70 Duro
66	Valve Sleeve O-Ring	70 Duro
67	End Cap O-Ring	70 Duro
68	End Cap O-Ring	70 Duro
69	Wiper	90 Duro
70	Valve Sleeve Back-Up Ring	Teflon
71	Holding Valve End Cap O-Ring	70 Duro
72	Manifold O-Ring	70 Duro
73	Seat-Poppet Guide O-Ring	70 Duro
74	Operator Port Cap O-Ring	70 Duro
75	Flow Control Check Spring	70 Duro
76	Flow Control Cap O-Ring	70 Duro
77	Flow Control Stem O-Ring	70 Duro
78	Flow Control Stem O-Ring	70 Duro
79	Flow Control Stem Back-Up Ring	Teflon
80	Relief Cap O-Ring	70 Duro
81	Relief Stem O-Ring	70 Duro
82	Relief Seat O-Ring	70 Duro
83	Suction Seat O-Ring	70 Duro
84	Suction Seat O-Ring	70 Duro
85	Body Manifold O-Ring	70 Duro
86	Discharge Check Seat O-Ring	70 Duro
87	Poppet O-Ring	70 Duro
88	Holding Valve Piston O-Ring	70 Duro
89	Holding Valve Piston Back-Up	Teflon
90	Suction Cap O-Ring	70 Duro
91	Ring Seal Spring	70 Duro
92	Ring Seal Spring	70 Duro
93	Relief Stem Spring	70 Duro
94	Relief Spring	70 Duro
95	Suction & Discharge Check Spring	70 Duro
96	Holding Valve Poppet Spring	70 Duro
97	Holding Valve Piston Wiper Ring	70 Duro
98	Relief Ball-Nylon	70 Duro
99	Check Valve Ball-Nylon	70 Duro
100	Hex Jam Nut	70 Duro
101	Instruction Plate	70 Duro
102	Plate Screws	70 Duro
103	Flush Plug-1/4 Taper	70 Duro
104	Flush Plug-1/4 Taper	70 Duro
105	Flush Plug-1/4 Taper	70 Duro
106	Flush Plug-1/4 Taper	70 Duro
107	Flush Plug-1/4 Taper	70 Duro
108	Hex Hd. Cap Screw	70 Duro
110	Soc. Hd. Cap Screw	70 Duro
111	Relief Valve	70 Duro
112	Flow Control Locknut	70 Duro
113	End Cap Back-Up Ring	70 Duro
114	End Cap Back-Up Ring	70 Duro
116	Flow Control Cap Back-Up Ring	70 Duro
117	Stem Back-Up Ring	70 Duro
118	1 Pipe Plug-1/4 Taper	70 Duro
119	Ring Seal Spring	70 Duro




HAND PUMP ASSEMBLY



Note: Numbers listed inside this symbol Δ pertain to the 4 cu. in pump and palm valve assembly.

PALM VALVE AND DOUBLE HOLDING VALVE ASSEMBLY



DISASSEMBLY OF PUMP AND VALVE COMPONENTS

(Refer to Pages 6 & 7)

Failure of the ram to "lock-up" as shown in Test #1 is a general indication of ring seal failure, suction check valve failure or manual relief check valve failure. Problem areas are usually due to a defective suction ball, discharge relief ball, ring seal or foreign matter imbedded in one or all three of the above mentioned components. A cut O-ring around the ring seal, suction check seat or discharge seat will produce the same malfunction.

NOTE: During any component disassembly all O-rings, wear rings, wipers and nylon balls should be replaced.

TO REMOVE THE MANUAL DISCHARGE RELIEF ASSEMBLY

- 1) Push the relief knob (51) in to neutralize any trapped gas or oil pressure in the system.
- 2) Pull both palm buttons (50) out into automatic position.
- 3) Remove the discharge relief knob (51), boot (49) and hex head cap (25), stem (23), and spring (93).
- 4) Place one hand over the discharge relief cavity and jerk the pump ram (7) down to "pop" the relief seat (24) up for removal.
- 5) Inspect the O-ring on the discharge relief seat (82), the chamfered seat and the nylon check ball (98) for scoring or deep scratches.

TO REMOVE VALVE SLEEVE ASSEMBLY

- 1) Push manual relief valve (51) down to neutralize any trapped gas or oil pressure in the system. (Neglect this if the relief assembly is already removed.)
- 2) Remove the palm valve knob (50), boot (48) and Palm Valve End Cap (34).
- 3) Carefully pull the stem (26) and valve sleeve assembly (17) out of the valve body (13).
- 4) Inspect the flat surfaces on the valve sleeve and the O-rings (68) on the stem (26).
- 5) To remove the pilot piston (15) inside the valve body (13) first remove the palm valve sleeve assembly (17). Care must be taken not to scratch or score the inside bore of the valve body. Replacement of the pilot piston O-rings (63) should be made at this time.

TO REMOVE THE RING SEAL ASSEMBLY

The valve sleeve assemblies for all pumps must be removed before removing the ring seal assemblies (18 and 19).

- 1) Disconnect the hydraulic tubing and fittings which connect the ports to the tanks and the discharge ports to the operator. The hex head cap retainers on the front face of the valve (13) also contain ring seal assemblies (19).

- 2) Remove hex head cap retainers (22 and 20) and springs (91 and 92).
- 3) Reach inside the valve body (13) through the valve sleeve hole and push the ring seals (18 and 19) out.
- 4) Inspect the flat faces of the ring seals (18 and 19) for wear and the O-rings (60 and 61) for cuts. Replacement of the ring seals (18 and 19) and O-rings (60 and 61) should be done at this time.

DISASSEMBLY OF PUMP AND VALVE COMBINATION

- 1) Remove the four assembly bolts (43) located on the back of the pump body (1).
- 2) Carefully pull the valve body (13) and pump body (1) apart to prevent loss of the mounting O-rings between the two blocks.
- 3) To remove the pump suction seat (10) inserted in the pump body (1) place one hand over the seat cartridge (10) and one finger to hold the nylon discharge ball on its seat and jerk the pump ram (7) downward to create pressure to "pop" the cartridge (10) out into your hand.
- 4) Inspect the seat O-rings (83 and 84), check the ball (99), and chamfered seat for scratches and foreign matter.
- 5) NOTE: This pertains to the 12 cu. in. pumps only. Remove the discharge check seat (35) and inspect O-rings (86) and chamfered seat for scratches and foreign matter.

DISASSEMBLY OF PUMP RAM AND PISTON

- 1) Remove the snap ring (X-washers) (53) located outside each pin (11 and 12) in the clevis pivot arm assembly (4) and (5).
- 2) Remove the pins (11 and 12) clevis (4) and pivot bar (5).
- 3) Remove the 4 pump head bolts (42) located at the top of the pump cylinder (1).
- 4) Carefully pull the ram (7) and piston assembly (6) out of the pump cylinder (1).
- 5) Inspect the ram (7), pump cylinder bore (1), piston O-ring (58) and piston wear rings (59), for scoring and excessive wear. The O-ring (56) and Poly Pak lip seal (54) and wiper rings (57) around each pump ram (7) and (8) should be replaced at this time. One O-ring (59), Poly Pak lip seal (54) and wiper ring (57) can be found in the pump head (2). The other set can be reached by unscrewing the hex shaped ram cover (9) at the bottom of the pump body (1).

(Continued on Page 9)

DISASSEMBLY PROCEDURE FOR DOUBLE HOLDING VALVE/PALM VALVE ASSEMBLY

- 1) Remove the operator port caps item (22) located at the top and bottom of the valve body item (13). Remove and inspect the cap O-rings item (75).
- 2) Remove the four hex head cap screws item (108) on each end of the valve body item (13). Remove the holding valve end caps item (33) and inspect O-ring item (71) and back-up ring (114), care should be taken not to lose the manifold O-ring item (72) when the cap (33) is removed.
- 3) Unscrew and remove the thermal relief valve item (111) from each end cap (33) and inspect the O-ring.
- 4) Remove the poppet guides (30), the spring (96) and the poppet assembly (28 and 29). NOTE: To disassemble (28 and 29) remove the locknut (100). The poppet (Nylon) can be removed from the poppet pin (28) inspect the O-ring (87) between the poppet (29) and the poppet pin (28).
- 5) Remove the seat/poppet guides (27) and inspect O-ring (73).
- 6) Remove the pilot piston (31) and inspect O-ring (88) and wear rings (97).


DISASSEMBLY OF THE SPEED CONTROL COMPONENTS (WHEN EQUIPPED)

- 1) Remove the four socket head cap screws (110) and remove the flow control cap (38) from the valve body (13). To remove the flow control knob (52) from the stem (39), the spring pin must be removed.
 - 2) Remove the locknut (112) and unscrew the stems (39) from the cap (38) inspect the O-ring and back-up ring (78 and 79).
 - 3) Remove the square head pipe plug (36). Remove the spring (76) and the check-ball (Nylon) (37).
- When the assembly is not equipped with the built-in speed control components remove the four socket head bolts and cap to replace the O-ring on the cap.

RECONDITIONING AND ASSEMBLY

RELAPPING THE VALVE SLEEVE

The valve sleeves (16 and 17) can be easily relapped to assure proper sealing surfaces; assuming the scratches in them are not too deep. Note each valve sleeve has four flat sides. Only the three with holes on them need to be relapped. A piece of plate glass and any valve grinding compound (Ajax, Babo or Comet) make an ideal relapping plate and lapping compound.



RECONDITIONING AND ASSEMBLY

RE-ASSEMBLY OF THE VALVE SLEEVE AND RING SEAL COMPONENTS

- 1) After relapping the valve sleeve items (16) and (17) the valve body (13) should be turned upside down in order to insert the ring seal spring items (119) and (91) on the 12 cubic inch model and items (19) on the 4 cubic inch model.


See Figure "1" for re-assembly of springs (91), (119) ring seals (18) with O-rings (60).

- 2) Install the springs (119) on 12 cubic inch model and (91) on the 4 cubic inch model and the rings seals (18). Note: The lapped surface closest to the O-ring groove on the ring seal is the end to be installed first.
- 3) Start to install the left valve sleeve (17) indicated left by the letter "L" stamped on the unit. In order to complete installation of the valve sleeve (17) into the body (13), the ring seal (18) has to be compressed about $\frac{1}{8}$ inch in order to allow the front end of the valve sleeve to slip by the ring seal and finally rest on the flat portion of the sleeve. Use a blunt instrument or tool to compress the ring seal (18) and spring (119) or (91) in order not to scratch the flat lapped surface of the ring seal.

NOTE: It is extremely important to insert the correct sleeve on each end of the valve body (13).

Each valve sleeve (16 and 17) has four holes drilled through the flat surfaces and one milled slot. One set of holes are 90° apart from each other and the other holes are drilled straight through. The 90° apart holes are smaller than the straight drilled through hole. When inserting the right valve sleeve (16) as shown in Figure "1" be sure to have the slot facing the bottom of valve body (13) and one of the 90° holes (smaller holes) should be facing the front of the valve body noted in Figure "1" by the sides or face with the instruction plate (101).

To complete one side of the sleeve ring seal installation, insert another ring seal (18) as shown in Figure "2" so that the flat surface closest to the O-ring groove on the ring seal (18) is away from the valve sleeve (16).



4 INCH DOUBLE HOLDING VALVE/PALM VALVE COMBINATION MANIFOLDED TO A 12 CUBIC INCH HAND PUMP


The following items pertain to the 4 inch/12 inch pump combination:

Item	Quantity	Description
122	1	O-Ring Discharge Check
123	2	Soc. Hd. Cap Screw
124	4	Soc. Hd. Cap Screw
125	1	O-Ring Suction Manifold
126	1	Manifold Plate

This assembly includes a manifold plate, item (35), to allow usage of a 12 cubic inch pump with the 4 inch valve combination.

The disassembly procedure is identical to the previously mentioned procedure with the exception of the following items:

Manifold plate, item (35), which bolts to the valve body, item (13), and to the pump body, item (1). This manifold, if first assembled to the valve body with two (2) cap screws, item (123) and four (4) cap screws, item (124), the cap screws, item (123), are to be installed at the top of the manifold and the cap screws, item (124), are to be installed near the bottom of the manifold. O-rings, items (122) and (125), are to be installed between the manifold and valve body along with the nylon check ball, item (99), and spring, item (95). After completion of the manifold mounting, the hand pump body can be bolted to the manifold with hex head bolts, items (43). O-rings, item (86) and (85), must be installed between the pump body and manifold plate.



THIS MANUAL PERTAINS TO THE FOLLOWING SHAFER ASSEMBLIES

BILL OF MATERIAL	PICTURE ASSEMBLY	DESCRIPTION
67558-FS	65980	12 Inch Pump / DHV Assembly 3/4" NPTF Ports with speed controls
67557-FS	66597	12 Inch Pump / DHV Assembly 3/4" NPTF Ports without speed controls
65980-FS	65980	12 Inch Pump / DHV Assembly 1" NPTF Ports with speed controls
66597-FS	66597	12 Inch Pump / DHV Assembly 1" NPTF Ports without speed controls
67280-FS	65980	12 Inch Pump / DHV Assembly 1 1/4" NPTF Ports with speed controls
67279-FS	66597	12 Inch Pump / DHV Assembly 1 1/4" NPTF Ports without speed controls
69460-FS	69460	4 Inch Pump / DHV Assembly 1/2" NPTF Ports with speed controls
69470-FS	69470	4 Inch Pump / DHV Assembly 1/2" NPTF Ports without speed controls
72007-FS	69460	4 Inch Pump / DHV Assembly 3/4" NPTF Ports with speed controls
72008-FS	69470	4 Inch Pump / DHV Assembly 3/4" NPTF Ports without speed controls
72060-FS	72057	12 Inch Pump Manifolder to 4 Inch DHV Assembly 1/2" NPTF Ports with speed controls
72061-FS	72062	12 Inch Pump Manifolder to 4 Inch DHV Assembly 1/2" NPTF Ports without speed controls
72058-FS	72057	12 Inch Pump Manifolder to 4 Inch DHV Assembly 3/4" NPTF Ports with speed controls
72059-FS	72062	12 Inch Pump Manifolder to 4 Inch DHV Assembly 3/4" NPTF Ports without speed controls

ShaferTM

valve operating systems

SHAHER VALVE COMPANY

2500 Park Avenue West, Mansfield, OH 44906 • Phone (419) 529-4311 • FAX (419) 529-3688 • TLX 810-448-2818

Form No. HP/DHV